8711 (051)

UPSTATE UPSTATE UPSTATE UPSTATE UPSTATE UPSTATE UPSTATE UPSTATE UPSTATE UPSTATE

OUR NEXT MEETING will be on Thursday November 19, 1987.

The December meeting will be December 17,1987.

PLACE: CAPITAL DISTRICT PSYCHIATRIC CENTER

New Scotland Ave. Next to Albany Medical Center

The program for the November meeting is as follows: Bob Burgess will give a demonstration on Plato. The Boftwaer Library Club will be present.

A NOTE to other Users Groups: The articles printed in the Upstate Newsletter may be reprinted if proper credit is given to the author and to the Upstate New York 99/4 Users Group.

IL'STATE 99/4A USERS BROUP
P.O. BOX 13522
ALBANY, N.Y. 12212
RETURN TO SENDER
LETTERS AND PRINTED MATTER
ADDRESSED TO FOREIGN COUNTRIES
MUST BE PLACED IN ENVELOPES
OR UNDER WRAPPERS
SEE: IMM 224.4/244.41

VOL V, NO. 9

November 1987

R.S. McDurnott EDITOR 233-1445

EDMONTON USERS GROUP P. O. BOX 11983 EDMONTON, ALBERTA T5J 3L1

HAVE YOU EVER WONDERED?

How many waym you can print a CHAR, to the screen.

There are several ways to print to the sreen.

From console basic.

A PRINT "A" Will print an A in the lower lefthand corner. B CALL HCHAR(12,14,65) Will print anA near the center of the screen.

- 2 From console basic with either E/A or MIN/MEM pluged in A CALL POKEY(300,16i) Will print an A near the center of the screen. With 300 being the screen location and 16i being the char. to be printed (65) plus the basic screen offset of 96 added.
- 3 From Extended basic
 - A PRINT "A" Will print an A in the lover lefthand corner.
 - B DISPLAY AT(12,14): "A" Will print an A near the center of the screen.
 - C CALL HCHAR(12,14,65) Will also print an A near the center of the screen.
 - D CALL INIT: CALL LOAD("D8K1.?xx"): CALL LINK("?xx") After creating the machine language subroutine.

4 With the EDIT/ABBM

A For use from E/A

- 1 REF VBBW Referenceing routine to write to VDP DEF RUN Defining program name
 - RUN LI RO,300 Loading register 0 with screen location

LI Ri,>4100 Loading register I with char to print

BLMP VBSW Call routine to write to VDP END End directive for assembler

- 2 Now wave and Assemble the source code.
- 3 Load using option 3 of the E/A and your file name.
- 4 Run bye using RUN as the program name.

B From Extended basic

1 Using the E/A editer.

DEF RUN Defining progame name for the cell link.

RUN LI R0,300 Loading register 0 with screen location
LI Ri,>Bi00 Loading register 1 with char to print

BLWP >2020 Call routine to write to VDP

RT Return directive to EB calling program
END End directive for asse.

- 2 Now save and assemble the source code.
- 3 Load from EB using CALL INIT, CALL LOAD ("DSK1, FILENAME"), CALL LINK("RUN")

I hope I have helped you to understand the many different ways of printing a single char, to the screen with this article, and not confused you to much. More to come??

BLVB

Phyllis has started a new TI board. Call 518-583-2193 9pm-12pm. It runs at 300 and 1200 baud. If you have trouble at 300 baud call Phyllis at 518-587-5661. She would like to get uploads so please send something to show your support.